

**TCs (Tetracyclines) ELISA Kit**

Catalog No: E-FS-E161

96T/96T\*3

<b>Version Number:</b>	V1.4
<b>Replace version:</b>	V1.3
<b>Revision Date:</b>	2025.08.01

This manual must be read attentively and completely before using this product.

If you have any problems, please contact our Technical Service Center for help.

Toll-free: 1-888-852-8623 Tel: 1-832-243-6086 Fax: 1-832-243-6017

Email: [techsupport@elabscience.com](mailto:techsupport@elabscience.com)

Website: [www.elabscience.com](http://www.elabscience.com)

Please kindly provide us the lot number (on the outside of the box) of the kit for more efficient service.

## Test principle

This kit uses Competitive-ELISA as the method for the quantitative detection. It can detect Tetracyclines (TCs) in samples, such as pork, eggs, etc. This kit is composed of ELISA Microtiter plate, HRP conjugate, antibody working solution, standard and other supplementary reagents. The microtiter plate in this kit has been pre-coated with coupled antigen. During the reaction, TCs in the samples or standard competes with coupled antigen on the solid phase supporter for sites of anti-TCs antibody. Then Horseradish Peroxidase (HRP) conjugate is added to each microtiter plate well, and substrate reagent is added for color development. There is a negative correlation between the OD value of samples and the concentration of TCs. The concentration of TCs in the samples can be calculated by comparing the OD of the samples to the standard curve.

## Technical indicator

**Reaction mode**(Incubation time and temperature): 25°C; 30 min, 15min

**Detection limit:** Pig urine ---50 ppb; Pork, chicken, duck ---20 ppb; Egg ---5 ppb; Pork liver ---30 ppb.

**Cross-reactivity:** Tetracycline ---285%; Chlortetracycline ---75%; Oxytetracycline ---80%;  
Doxycycline ---100%.

**Sample recovery rate:** 90%±30%.

## Kits components

Item	Specifications
ELISA Microtiter plate	96 wells
Standard Liquid	1.5/1.5*3 mL each (ppb=ng/mL=ng/g) (0 ppb, 0.5 ppb, 1.5 ppb, 4.5 ppb, 13.5 ppb, 40.5 ppb)
HRP Conjugate	7/7*3 mL
Antibody Working Solution	7/7*3 mL
Substrate Reagent A	7/7*3 mL
Substrate Reagent B	7/7*3 mL
Stop Solution	7/7*3 mL
20×Concentrated Sample Diluent	25/25*3 mL
20×Concentrated Wash Buffer	25/25*3 mL
10×Concentrated Sample Extract	50/50*3 mL
Plate Sealer	3/9 pieces
Sealed Bag	1/3 piece
Manual	1 copy

Note: All reagent bottle caps must be tightened to prevent evaporation and microbial pollution.

---

**Other materials required but not supplied**

**Instruments:** Microplate reader, Printer, Homogenizer, Vortex mixer, Centrifuge, Graduated pipette, Balance (sensitivity 0.01 g).

**Micropipette:** Single channel (20-200 µL, 100-1000 µL), Multichannel (30-300 µL).

**Reagents:** Acetonitrile, Trichloroacetic acid.

**Notes**

1. The overall OD value will be lower when reagents have not been brought to room temperature before use or room temperature is below 25°C.
2. If the wells turn dry during the washing procedure, it will lead to bad linear standard curve and poor repeatability. Operate the next step immediately after wash.
3. Mix thoroughly and wash the plate completely. The consistency of wash procedure can strongly affect the reproducibility of this ELISA kit.
4. FOR RESEARCH USE ONLY. ELISA Microtiter plate should be covered by plate sealer. Avoid the kit to strong light.
5. **Each reagent is optimized for use in the E-FS-E161. Do not substitute reagents from any other manufacturer into the test kit. Do not combine reagents from other E-FS-E161 with different lot numbers.**
6. Substrate Reagent should be abandoned if it turns blue color. When OD value of standard (concentration: 0) < 0.8 unit (A450nm < 0.8), it indicates the reagent be deteriorated.
7. Stop solution is caustic, avoid contact with skin and eyes.
8. As the OD values of the standard curve may vary according to the conditions of the actual assay performance (e.g. operator, pipetting technique, washing technique or temperature effects), the operator should establish a standard curve for each test.
9. Even the same operator might get different results in two separate experiments. In order to get reproducible results, the operation of every step in the assay should be controlled.
10. **For mentioned sample fast and efficient extraction methods are included in the kit description. Please consult technical support for the applicability if other sample need to be tested.**
11. The kit is used for rapid screening of actual samples. If the test result is positive, the instrument method such as HPLC, LC/MS, etc. can be used for quantitative confirmation.

**Storage and expiry date**

Store the kit at 2-8°C. Do not freeze any test kit components.

Return any unused microwells to their original foil bag and reseal them together with the desiccant provided and further store at 2-8°C.

**Expiry date:** expiration date is on the packing box.

---

## Experimental preparation

Restore all reagents and samples to room temperature before use.

Open the microplate reader in advance, preheat the instrument, and set the testing parameters.

### 1. Sample pretreatment Notice:

Experimental apparatus should be clean, and the pipette should be disposable to avoid cross-contamination during the experiment.

### 2. Solution preparation

*Please prepare solution according to the number of samples. Don't use up all components in the kit at once!*

Solution 1: 1M Trichloroacetic acid

Accurately weigh 16.4g **Trichloroacetic acid** in glass bottle, add deionized water to dissolve and constant volume to 100mL.

Solution 2: Sample Diluent A

Dilute the **20×Concentrated Sample Diluent** with deionized water.

(**20×Concentrated Sample Diluent** (V): deionized water (V) =1:19).

Solution 3: Sample Diluent B

Dilute the **20×Concentrated Sample Diluent** with deionized water.

(**20×Concentrated Sample Diluent** (V): deionized water (V) =1:7).

Solution 4: Wash Buffer

Dilute the **20×Concentrated Wash Buffer** with deionized water. (20×Concentrated

Wash Buffer (V): Deionized water (V) =1:19)

### 3. Sample pretreatment procedure

#### 3.1 Pretreatment of Pig urine sample:

- (1) Take 980μL **Sample Diluent A (Solution 2)** into a centrifuge tube, add 20μL fresh pig urine sample, swirl for 10s, and mix well.
- (2) Take 50 μL for analysis.

**Note: Sample dilution factor: 50, detection limit: 50 ppb.**

#### 3.2 Pretreatment of Pork, chicken, duck sample:

- (1) Remove fat from sample, homogenize the sample with homogenizer.
- (2) Weigh 2±0.05 g of homogenate sample into the 50 mL centrifuge tube.
- (3) Add 3.6mL deionized water and 0.4mL **10×Concentrated Sample Extract** successively and swirl violently for 2min.
- (4) Centrifuge at 4000 r/min at room temperature for 5 min.
- (5) Take 100μL of the intermediate layer liquid, add it to 900μL **Sample Diluent B (Solution 3)**, and vortex fully for 30 seconds.
- (6) Take 50 μL for analysis.

**Note: Sample dilution factor: 20, detection limit: 20 ppb.**

**3.3 Pretreatment of Eggs sample:**

- (1) Weigh  $2\pm0.05$  g of homogenate sample into the 50 mL centrifuge tube.
- (2) Add 3.6mL deionized water and 0.4mL **10×Concentrated Sample Extract** successively and swirl violently for 2min.
- (3) Centrifuge at 4000 r/min at room temperature for 5 min.
- (4) Take 50  $\mu$ L of supernatant for analysis.

**Note: Sample dilution factor: 3, detection limit: 5 ppb.**

**3.4 Pretreatment of Pork liver sample:**

- (1) Weigh  $1\pm0.05$  g of homogenate sample into the 10 mL centrifuge tube.
- (2) Add 0.2mL **1M Trichloroacetic acid (Solution 1)** and 1mL Acetonitrile successively, and immediately vortex fully for 1min. (Vortices are required until the tissue is completely dispersed)
- (3) Centrifuge at 4000 r/min at room temperature for 5 min.
- (4) Take 100  $\mu$ L of supernatant into the centrifuge tube, add 900  $\mu$ L of **Sample Diluent A (Solution 2)**, vortex for 1 min.
- (5) Take 50  $\mu$ L for analysis.

**Note: Sample dilution factor: 20, detection limit: 30 ppb.**

**Assay procedure**

Restore all reagents and samples to room temperature (25°C) before use. All the reagents should be mixed thoroughly by gently swirling before pipetting. Avoid foaming. The unused ELISA Microtiter plate should be sealed as soon as possible and stored at 2-8°C.

1. **Number:** Number the sample and standard in order (multiple well), and keep a record of standard wells and sample wells. **Standard and Samples need test in duplicate.**
2. **Add Sample:** add 50  $\mu$ L of **Standard or Sample** per well,
3. Then add 50  $\mu$ L **HRP conjugate** to each well.
4. Then add 50  $\mu$ L **Antibody Working Solution** to each well, cover the plate with plate sealer, oscillate for 5 s gently to mix thoroughly, incubate at  $25\pm2^\circ\text{C}$  for 30 min in shading light.
5. **Wash:** uncover the sealer carefully, remove the liquid of each well. Immediately add 260  $\mu$ L of **Wash Buffer (Solution 4)** to each well and wash. Repeat wash procedure for 4 times, 30 s intervals/time. Invert the plate and pat it against thick clean with absorbent paper (If bubbles exist in the wells, clean tips can be used to prick them).
6. **Color Development:** add 100  $\mu$ L of **Substrate Reagent A** and **Substrate Reagent B** mixture. (**Substrate Reagent A** and **Substrate Reagent B** are mixed 1:1 according to volume, must be fully mixed, the mixture is used within 5 minutes, avoid the use of metal container, avoid stirring reagents.) Gently oscillate for 5 s to mix thoroughly. Incubate  $25^\circ\text{C}$  for 15-20 min at in shading light.
7. **Stop Reaction:** add 50  $\mu$ L of **Stop Solution** to each well, oscillate gently to mix thoroughly.
8. **OD Measurement:** determine the optical density (OD value) of each well at 450 nm (reference wavelength 630 nm) with a microplate reader. This step should be finished in 10 min after stop

reaction.

## Result analysis

1. **Absorbance% =  $A/A_0 \times 100\%$**

A: Average absorbance of standard or sample

$A_0$ : Average absorbance of 0 ppb Standard

2. **Drawing and calculation of standard curve**

Create a standard curve by plotting the absorbance percentage of each standard on the y-axis against the log concentration on the x-axis to draw a semi-logarithmic plot. Add the average absorbance value to standard curve to get corresponding concentration. **If samples have been diluted, the concentration calculated from the standard curve must be multiplied by the dilution factor.**

For this kit, it is more convenient to use professional analysis form for accurate and fast analysis on a large number of samples.

**Tetracyclines (E-FS-E161) Standard Curve**

